

Product 535287



535287 Holder with lock. Active holder with cig-plug and tilt swivel. 2 keys included.

This holder is to be used when you want to secure your Galaxy Tab and still have it easy accessible. The holder is crashtested and approved for use on Brodit's headrest mount.

The holder is also perfect for use in stores, at exhibitions and any place where you want to use your Galaxy Tab without having it easy removable. The holder is made of extra strong plastic and is equipped with a lock. In order to remove the Galaxy Tab from the holder you need the key, two keys are included. The holder is mounted onto a tilt swivel. This mean that you can adjust the angle in order to avoid light reflection on the screen. You can easily switch between portrait and landscape mode by turning the holder into desired position.

Tablets should not be installed onto a car's dashboard if blocking the view or key controls. ProClip is designed for use with smaller devices like smartphones. If you want to place a tablet onto a dashboard, each combination of tablet-car must be examined in detail by yourself in order to determine if such an installation is possible in the specific case. Brodit will not give any recommendations for such installations. An installation of a tablet onto a vehicle's dashboard is always done on the customer's own responsibility. Brodit recommends using tablets on the car's headrest, installed onto a Brodit headrest mount.

Film Crash test on similar holder, front crash.

Film Crash Test of similar holder, rear crash.

EAN: 7320285352872

Item no 535287 fits:

Samsung Galaxy Tab 10,1 GT-P7500

INSTALLATION INSTRUCTIONS

1.



2.



3.



4.



Please read all of the instructions and look at the pictures before attaching the holder.

1. Loosen the screw in the center of the holder so you can remove the tilt swivel attaching plate on the back. Place the attaching plate onto the desired position. Screw the attaching plate into place with the enclosed screws. Place the holder over the attaching plate so the screw fits in the hole in the tilt swivel. Screw the holder onto the attaching plate. Tighten the screw so the holder is firmly in place, but still can be adjusted.
 2. Slide the device carefully into the holder from above. Press the lock onto the top part of the holder. Press the button to lock.
 3. Use the enclosed key to open the lock. Remove the lock by sliding it upwards away from the holder. Slide the device upwards carefully out of the holder.
 4. The holder is in place. Switch between portrait and landscape mode by turning the holder into desired position.
-